

AVVERTENZE PER L'USO E IL MANTENIMENTO

- Tenere fuori dalla portata dei bambini.
 - Utilizzare il prodotto solo per l'uso previsto.
 - Non utilizzare in caso di danni evidenti o parti mancanti.
 - Non esporre il prodotto a fonti di calore, fiamme libere o umidità.
 - Evitare il contatto diretto con superfici calde o materiali infiammabili.
 - Non modificare o alterare il prodotto in alcun modo.
 - In caso di malfunzionamento, interrompere immediatamente l'uso.
 - Smaltire il prodotto e il suo imballaggio secondo le normative locali in materia di rifiuti.
-
- Utilizzare il baule esclusivamente per stoccaggio di materiali e attrezzi: non è progettato per il trasporto di persone o animali.
 - Non superare il carico massimo indicato dal produttore; la struttura potrebbe deformarsi o perdere stabilità.
 - Durante l'apertura e la chiusura, tenere mani e dita lontane dalla zona delle cerniere per evitare schiacciamenti.
 - Le catene laterali servono a sostenere il coperchio: non tirarle e non modificarle.
 - Non lasciare il coperchio aperto in presenza di bambini o in zone ventose: il coperchio potrebbe chiudersi improvvisamente.
 - Chiudere sempre con lucchetto quando non in uso, per evitare aperture accidentali.
 - Non salire sul coperchio né utilizzare il baule come sgabello o piattaforma.
 - Posizionare su superficie piana e stabile; evitare l'uso su terreni inclinati.
 - Pulire con panni morbidi e detergenti non abrasivi; evitare prodotti corrosivi che possono danneggiare la superficie.
 - Non conservare materiali infiammabili o pericolosi.
 - Per qualunque problema o difetto si riscontri prima o durante l'utilizzo, rivolgersi al proprio rivenditore fisico o online.

WARNINGS FOR USE AND MAINTENANCE

- Keep out of the reach of children.
 - Read the instructions carefully before use.
 - Use the product only for its intended use.
 - Do not use if there is obvious damage or missing parts.
 - Do not expose the product to sources of heat, open flames or moisture.
 - Avoid direct contact with hot surfaces or flammable materials.
 - Do not modify or alter the product in any way.
 - In case of malfunction, discontinue use immediately.
 - Dispose of the product and its packaging according to local waste regulations.
- Use the tool chest exclusively for storing tools and materials; it is not designed for transporting people or animals.
- Do not exceed the maximum load indicated by the manufacturer; the structure may deform or lose stability.
 - Keep hands and fingers away from the hinge area during opening and closing to avoid crushing injuries.
 - The side chains are designed to support the lid: do not pull or modify them.
 - Do not leave the lid open near children or in windy areas: it may close unexpectedly.
 - Always secure the lid with a padlock when not in use to prevent accidental opening.
 - Do not stand or sit on the lid, and do not use the tool chest as a stool or platform.
 - Place on a flat and stable surface; avoid using on sloped or uneven ground.
 - Clean with soft cloths and non-abrasive detergents; avoid corrosive products that may damage the surface.
 - Do not store flammable or hazardous materials.
 - For any problem of defect you may encounter before or during use, please refer to your in-store or online retailer.