

MANUALE D'ISTRUZIONI / INSTRUCTION MANUAL

ART.C2592188—CARRELLO PORTAUTENSILI 3 RIPIANI C/PANNELLO PREFORATO PRE-DRILLED TOOL TROLLEY 3 TIERS W/PRE-DRILLED TOOL PANEL



1. Fissare le ruote sul telaio con i bulloni a testa esagonale; entrambe le fisse vanno affiancate su un lato corto, entrambe le pivottanti sul lato corto opposto. Fissare le ruote pivottanti sullo stesso lato della maniglia / *First, screw the wheels to the chassis. Both fixed casters and the swivel casters must be installed on the short side. Use the hex bolts. Fix the swivel casters on the same side of the handle.*
2. Usare le viti per installare i pannelli preforati laterali al ripiano inferiore. Attenzione a non montare i pannelli al contrario! Installare poi il ripiano intermedio e infine il ripiano superiore. / *Use bolts to assemble the side preforated panels to the bottom tier. Be careful not to assemble the side panels upside down! Then install the middle tier and finally the top tier.*
3. Monta la maniglia usando i fori del pannello / *Install handle through the holes of the side panel.*
4. Infine, installa il pannello preforato posteriore sul ripiano superiore usando i supporti triangolari. / *Finally, install the upper back preforated panel on the top tier using the triangle brackets supports.*